



POSIES SUPER SLIDE SPRINGS AND HOT ROD PARTS

219 N. Duke Street Hummelstown, PA 17036
Phone 717.566.3340 Fax 717.566.5440

1932 FORD 3 POSITION ADJUSTABLE WELD ON REAR KIT

**DRIVERS SIDE
OUTSIDE VIEW**



TOP VIEW OF FRAME



DRIVER'S SIDE FRAME INSIDE VIEW

AXLE CENTER LINE

CUT 1 1/8" HOLE IN THE SIDE OF THE FRAME RAIL FOR HANGER SLEEVE 15/16" ON CENTER FROM THE BOTTOM OF THE FRAME RAIL



MOUNT GUSSET AGAINST REAR CROSSMEMBER. TRIMMING MAY BE NEEDED DEPENDING ON FRAME AND STYLE OF CROSSMEMBER.

NOTE:

- MAKE SURE THAT THE FRAME IS LEVEL AND SQUARE
- THE MOUNTING BRACKETS MUST BE FULLY WELDED BEFORE FINAL INSTALLATION

KIT INCLUDES:

- | | |
|---|------------------------------|
| (2) FRONT WELD-ON SPRING PERCHES | (2) U-BOLT PLATES |
| (2) BOLTS & LOCK NUTS FOR FRONT OF SPRING | (2) HANGER SLEEVES & GUSSETS |
| (2) AXLE SADDLES | (2) SHACKLES |
| (4) U-BOLTS & NUTS | (2) LOWER SHOCK MOUNTS |
| | (2) SUPERSLIDE SPRINGS |

IMPORTANT:

MAKE SURE THAT YOU TIGHTEN THE SHACKLE NUTS SO THAT THE LAST THREAD IS PAST THE NUT. YOUR SHACKLE BUSHINGS WILL THEN LAST MANY MILES AND WORK CORRECTLY. OVER TIGHTENING OF THE SHACKLE NUTS AND FRAME MOUNT BOLT MAY RESULT IN A COMPROMISED RIDE QUALITY.

